

# Installation Instructions



1. Remove GreaseShot set at 1200mm AFFL to top



2. Identify the 4 fixing holes to the rear



3. Twist anti-clockwise to remove the cone



4. Level, mark the top holes



5. Mark bottom holes, drill & fix screws supplied.



6. Ensure the tube is inserted



7. Lock in cone clockwise, insert empty bottle



8. Fix the timer box to the wall, **DO NOT** reduce the tube between the doser and the box. Drill an 8mm hole in the drain pipe & insert lower pipe into the hole, once in silicone around the edges.



9. Once inserted into the pipe, peel the backing off the brackets to secure the tube



T: 0121 293 0800  
sales@kitchenflowsolutions.co.uk  
www.kitchenflowsolutions.co.uk