

Installation Instructions



1. Remove GreaseShot set at 1200mm AFFL to top



2. Identify the 4 fixing holes to the rear



3. Twist anti-clockwise to remove the cone



4. Level, mark the top holes



5. Mark bottom holes, drill & fix screws supplied.



6. Ensure the tube is inserted



7. Lock in cone clockwise, insert empty bottle



8. Drill a 4mm hole in the drain pipe & insert male insert, once in silicone around the edges.



9. Once inserted into the pipe, peel the backing off the brackets to secure the tube